

Reprogramming additional Remote Controls to system:

Note you can code a maximum of **three transmitters** at a time to any one system.

1. Disarm the system open then close the driver's door
2. Within 30 seconds after you have disarmed the system you turn the ignition on and off **20 times** finishing with the ignition in the off position.
3. Wait for 30 seconds and if the correct format has been followed the indicators if connected will flash 3 times to confirm entry to the coding procedure. If the indicators do not flash a confirmation please start again or check the alarm wiring connections.
4. Press button "B" of a new remote control within 20 seconds of entering programming, the indicators will flash and the siren will chirp once to confirm coding, additional remotes or existing remotes will have to be coded at this stage (within 20 seconds) by simply pressing each remote control button "B" once, (Maximum of 3 remotes) the indicators will flash and the siren will chirp once, when each remote has been coded to alarm system.
5. When the remotes required are coded the system will automatically exit the procedure after 20 seconds. All remote controls that have been entered will now be coded to the alarm system.